

Water Heater| (R-4.5)

InfraStop® Installation Instructions



1. InfraStop® Insulation
2. InfraStop® Insulation Spacer Strips
3. Water Heater

Tools Required:

Safety Glasses
Tape Measure
Utility Knife/Scissors

Recommended Products:

Reflective/Bubble/Bubble/Reflective - Roll: ISFDF48025 (48"x 25')

Installation Instructions:

- Cut three 2" wide strips of the InfraStop® Reflective/Bubble/Bubble/Reflective product at twice the circumference of the water heater (to be utilized as spacers).
- Attach the three strips (doubled) around the circumference of the water heater (top, bottom and middle).
- Cut the InfraStop® at a width equal to the height of the water heater. Secondly, cut the length of the product equal to the circumference measured on the outside of the spacers plus 1".
- If the water heater is taller than 48", a section of product will need to be fashioned to make up the shortage. The seam between the 48" sheet and the "extension" piece will need to be taped with InfraStop® Foil Tape on both sides.
- Wrap the InfraStop® around the water heater and tape the vertical seam with InfraStop® Foil Tape.
- Trim product around pressure valve and cut on both sides of thermostat housing to create a flap type cover for easy access. Additionally, cut product away from the cover of the lower access panel.

- Note: Electric Water Heaters Only - Cut a circular section of the product the size of the top of the water heater - trim to accommodate wires, pipes and relief valve. Tape (foil) the circular product section to the top of the water heater. **DO NOT USE PRODUCT ON TOP OF GAS WATER HEATERS.**
- Note: Electric Water Heaters - Check to insure heater is wired to meet local codes.
- **Note: Gas Water Heaters - Do not install the insulation below the bottom of the water heater tank -This area is to allow combustion air.**
- Note: All Water Heaters - Refer to owners or operating manual and follow any instructions provided for insulating the unit.

Review These Important Safety Guidelines Prior to Installation:

- **ALWAYS** check local building codes before installing InfraStop®.
- **ALWAYS** check the area you are insulating and make any needed repairs. Any worn wiring should be replaced before you begin installing InfraStop®.
- **ALWAYS** make sure work areas are well ventilated and well lighted.
- **ALWAYS** use eye protection when operating a staple gun.
- **ALWAYS** use caution and common sense when using a staple gun. Be aware of where electrical wiring is located. Stapling into a wire can cause severe shock or death. **NEVER** staple into electrical wiring.
- **ALWAYS** be careful when working with large pieces of InfraStop® on windy days.
- When installing InfraStop® on bright sunny days, it is best to wear sun glasses.
- Do not work in areas such as attics when temperatures are too hot.
- Visit our website at **www.insulationstop.com** for additional product and installation information.

Please Note:

The intention of these Installation Instructions and 3-D renderings are for the sole purpose of illustrating the correct location and relative position of the InfraStop® products in specific building assemblies. The correct construction methods and techniques are the responsibility of the installer or contractor. The methods outlined are recommendations on location of the InfraStop® products as a guideline. There are no claims on the part of InfraStop® that these building assemblies are finite standards or meet building code requirements (as they can vary by region).

InfraStop®

www.insulationstop.com

Phone: 800-871-0410

Fax: 888-838-5376

Email: customer.support@insulationstop.com