


Concrete Slab Insulation |(R-1.1)

Product: Concrete Slab Insulation

InfraStop® Installation Instructions



1. InfraStop® Concrete Slab Insulation
2. Concrete
3. Concrete Reinforcing Wire
4. Base Material

Tools Required:

Safety Glasses
Tape Measure
Utility Knife
Flat Edge Taping Tool

Note: Installation instructions and illustrated drawings are recommendations only, while proper local construction methods are the responsibility of the installer.

Recommended Products:

Concrete Slab Insulation, White/Reflective/Bubble/Bubble - Roll:
ISCP48050 (48"x 50'), ISCP48100 (48"x 100'), ISCP48125 (48"x 125')

Installation Instructions:

- Unroll the InfraStop® Concrete Slab Insulation product over the base material prior to pouring the concrete.
- Butt the seams of the product and seal with 3" wide poly tape. Note: Utilize a flat edge taping tool to assure good adhesion on all tape.
- Pour slab per code specifications.

Review These Important Safety Guidelines Prior to Installation:

- **ALWAYS** check local building codes before installing InfraStop®.
- **ALWAYS** check the area you are insulating and make any needed repairs. Any worn wiring should be replaced before you begin installing InfraStop®.
- **ALWAYS** make sure work areas are well ventilated and well lighted.
- **ALWAYS** use eye protection when operating a staple gun.
- **ALWAYS** use caution and common sense when using a staple gun. Be aware of where electrical wiring is located. Stapling into a wire can cause severe shock or death. **NEVER** staple into electrical wiring.
- **ALWAYS** be careful when working with large pieces of InfraStop® on windy days.
- When installing InfraStop® on bright sunny days, it is best to wear sun glasses.
- Do not work in areas such as attics when temperatures are too hot.
- Visit our website at **www.insulationstop.com** for additional product and installation information.

Please Note:

The intention of these Installation Instructions and 3-D renderings are for the sole purpose of illustrating the correct location and relative position of the InfraStop® products in specific building assemblies. The correct construction methods and techniques are the responsibility of the installer or contractor. The methods outlined are recommendations on location of the InfraStop® products as a guideline. There are no claims on the part of InfraStop® that these building assemblies are finite standards or meet building code requirements (as they can vary by region).

InfraStop®

www.insulationstop.com

Phone: 800-871-0410

Fax: 888-838-5376

Email: customer.support@insulationstop.com