
Radiant Floor - Concrete Slab | (R-1.1) Product: Concrete Slab Insulation

InfraStop[®] Installation Instructions



- 1. InfraStop[®] Concrete Slab Insulation
- 2. Finished Floor Surface
- 3. Concrete
- 4. Poly Tubing
- 5. Concrete Reinforcing Wire
- **6.** Base Material

Tools Required:

Safety Glasses

Tape Measure

Utility Knife/Scissors

Flat Edge Taping Tool

Note: Installation instructions and illustrated drawings are recommendations only, while proper local construction methods are the responsibility of the installer.

Recommended Products:

Concrete Slab Insulation, White/Reflective/Bubble/Bubble - Roll: ISCP48050 (48"x 50"), ISCP48100 (48"x 100"), ISCP48125 (48"x 125")

Installation Instructions:

- Unroll the InfraStop[®] Concrete Slab Insulation product over the base material prior to pouring the concrete.
- Butt the seams of the product and seal with 3" wide poly tape. Note: Utilize a flat edge taping tool to assure good adhesion on all tape.
- Install Radiant Floor System per manufacturer's specifications.

Review These Important Safety Guidelines Prior to Installation:

- ALWAYS check local building codes before installing InfraStop[®].
- ALWAYS check the area you are insulating and make any needed repairs. Any worn wiring should be replaced before you begin installing InfraStop[®].
- ALWAYS make sure work areas are well ventilated and well lighted.
- ALWAYS use eye protection when operating a staple gun.
- ALWAYS use caution and common sense when using a staple gun. Be aware of where electrical wiring is located. Stapling into a wire can cause severe shock or death. NEVER staple into electrical wiring.
- <u>ALWAYS</u> be careful when working with large pieces of InfraStop[®] on windy days.
- When installing InfraStop® on bright sunny days, it is best to wear sun glasses.
- Do not work in areas such as attics when temperatures are too hot.
- Visit our website at www.insulationstop.com for additional product and installation information.

Please Note:

The intention of these Installation Instructions and 3-D renderings are for the sole purpose of illustrating the correct location and relative position of the InfraStop® products in specific building assemblies. The correct construction methods and techniques are the responsibility of the installer or contractor. The methods outlined are recommendations on location of the InfraStop® products as a guideline. There are no claims on the part of InfraStop® that these building assemblies are finite standards or meet building code requirements (as they can vary by region).

InfraStop®

www.insulationstop.com Phone: 800-871-0410 Fax: 888-838-5376

Email: customer.support@insulationstop.com