


# PF Bldg / Roof / Retro / Bottom of Trusses

## InfraStop® Installation Instructions



1. InfraStop® Insulation
2. Exterior Roof Panel
3. Purlin
4. Truss
5. 1"x 2" (Nominal) Furring Strip

### Tools Required:

- Safety Glasses
- Tape Measure
- Utility Knife
- Staple Gun

### Recommended Products:

Reflective/Bubble/Bubble/Reflective - Roll: ISFDF48100 (48" x 100')

### Bottom of the Trusses

Open Interior

R-10\* Heat Flow Down (and a Radiant Barrier) | R-3.7\* Heat Flow Up

**Please Note:** In addition to the stated R-value, this application also provides a Radiant Barrier.

As a result, a 96% reduction of the radiant energy that ordinarily would be transmitted to the interior of the building is blocked.

### Installation Instructions:

- Pre-installation inspection - Check the roof area for clutter, water sprinklers, conduit and lights. Sprinkler systems are especially important. All water pipes must be below the InfraStop® Reflective/Bubble/Bubble/Reflective product to prevent the possibility of freezing in the winter.
- Nail 1"x 2" furring strips on the bottom of and perpendicular to the trusses on 22" centers. (Note: When truss spacing is 24" it is recommended to install the InfraStop® 24" or 48" product directly to the bottom cord of the truss.) >

- Butt the furring strips together and tape. Staple tape for reinforcement.
- Staple the edges of the InfraStop® to the furring strips with the 3/4” tabs (so that they will overlap at the seam).
- Tape the seams with a InfraStop® Foil Tape (goal is an air-tight, snug seam seal).
- Tape any butt seams with InfraStop® Foil Tape, insure taped seam has a good full continuous bond.
- Staple product at approximately 4” intervals down the middle of the sheet into the furring strip above.

\* Includes thermal resistance of 1.32 UP and 4.55 DOWN for interior air film.

**Calculation Disclaimer:** All values are calculated based on the “ASHRAE Handbook of Fundamentals” heat flow up and down.

### **Review These Important Safety Guidelines Prior to Installation:**

- **ALWAYS** check local building codes before installing InfraStop®.
- **ALWAYS** check the area you are insulating and make any needed repairs. Any worn wiring should be replaced before you begin installing InfraStop®.
- **ALWAYS** make sure work areas are well ventilated and well lighted.
- **ALWAYS** use eye protection when operating a staple gun.
- **ALWAYS** use caution and common sense when using a staple gun. Be aware of where electrical wiring is located. Stapling into a wire can cause severe shock or death. **NEVER** staple into electrical wiring.
- **ALWAYS** be careful when working with large pieces of InfraStop® on windy days.
- When installing InfraStop® on bright sunny days, it is best to wear sun glasses.
- Do not work in areas such as attics when temperatures are too hot.
- Visit our website at [www.insulationstop.com](http://www.insulationstop.com) for additional product and installation information.

### **Please Note:**

*The intention of these Installation Instructions and 3-D renderings are for the sole purpose of illustrating the correct location and relative position of the InfraStop® products in specific building assemblies. The correct construction methods and techniques are the responsibility of the installer or contractor. The methods outlined are recommendations on location of the InfraStop® products as a guideline. There are no claims on the part of InfraStop® that these building assemblies are finite standards or meet building code requirements (as they can vary by region).*

## **InfraStop®**

www.insulationstop.com

Phone: 800-871-0410

Fax: 888-838-5376

Email: [customer.support@insulationstop.com](mailto:customer.support@insulationstop.com)